



Consumers' Choice

How To Measure Your Windows

The first thing that you should do is measure all the windows that you would like tinted before ordering any Pro-Tint window film product. Remember only measure the glass area; do not include the window frame or gasket areas.

Pro-Tint residential and commercial window film measurements are measured on the inside of your home or business window(s). Pro-Tint window films are designed for interior applications and are not manufactured for outside installations.

Items needed for taking window measurements:

- Tape measure
- Pen and paper
- Calculator

When reading your tape measure write down the exact measurement or round up to the next 1/8 of an inch. When you are measuring your windows always measure in linear inches such as; 14 inches instead of 1 foot 2 inches.

Example: You have four windows that you want to apply Pro-Tint window film on.

Window Measurement Chart

<u>Window No.</u>	<u>Window Width</u>	<u>Window Height</u>
1	33 1/4"	61 1/2"
2	31 3/4"	48
3	34 1/2"	39 3/4"
4	28 1/4"	52 1/4"
		201.50 sub-total running inches
		+ 4.00 added extra for cutting
		205.50 total running inches

Figure what roll size to use:

Since Pro-Tint residential/commercial films come in 24", 36" and 60" window film material, you now know that all four of your four windows will need a 36" wide roll.

Figure what roll length to use:

First take your four total windows that added up to 201.50 and add one inch to each window measurement width and/or height thus allowing that extra room for correct trimming to size. This will allow the window film to cover the glass and allow you to have enough film to tint all your windows.

You now have to convert running inches to linear feet.

12 divided into 205.50 = 17.13 running feet. This means that a 25 foot roll is needed.

Ordering Film:

You would now order a Pro-Tint 36" x 25' roll of film to tint your four windows.